

TAPE DISPENSERS • LABEL DISPENSERS • NON-ADHESIVE CUTTERS

## LabelMoto DISPENSER Parts List

Part #	Description	Image	Notes	Used On	Pr	rice
ASM-005-01	Wire Harness for AC Dispensers	A SEE SEE SEE SEE SEE SEE SEE SEE SEE SE	This part number includes all of the wires to assemble electrical components	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$	13.90
ASM-006-01	BRUSH & BRUSH HOLDER ASSEMBLY FOR LD5000		2 Parts assembled together; not sold individually.	LD5000 Series	\$	20.90
ASM-006-02	BRUSH & BRUSH HOLDER ASSEMBLY FOR LD6000		2 Parts assembled together; not sold individually.	LD6000 Series	\$	22.90
ASM-006-03	BRUSH & BRUSH HOLDER ASSEMBLY FOR LDX6000		2 Parts assembled together; not sold individually.	LDX6000 Series	\$	26.90
ASM-006-05	BRUSH & BRUSH HOLDER ASSEMBLY FOR LD3000		2 Parts assembled together; not sold individually.	LD3000	\$	16.90
ASM-006-05-1	BRUSH & BRUSH HOLDER ASSEMBLY FOR LD3500		2 Parts assembled together; not sold individually.	LD3500	\$	16.90
ASM-006-06	BRUSH & BRUSH HOLDER ASSEMBLY FOR LDX8000		2 Parts assembled together; not sold individually.	LDX8000 Series	\$	27.60
ASM-006-08	BRUSH & BRUSH HOLDER ASSEMBLY FOR LD8000		2 Parts assembled together; not sold individually.	LD8000 Series	\$	23.40
ASM-007-01	PCB (Only) for LD3000 AND LD3500		To properly mount, spacer mounting hex screws (OTS-024-01) and screws (OTS-026-01) are needed	LD3000 & LD3500	\$	73.30
ASM-009-01	Wire Harness for LD3000 (PCB to Motor)		Connects Motor to PCB	LD3000 & LD3500	\$	6.70
ASM-012-01	AC Wiring Plate WITH Power Inlet and Switch		On/Off Switch, Power Inlet assembled on Metal component to easily install in machine.	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$	15.80
ASM-013-01	DC Photo-Sensor with Terminal for LD3000 & LD3500			LD3000 & LD3500	\$	94.90
ELE-002-01	Insulated Terminal for Wire Harness (Lug, Press On)		Used to crimp onto wire of Motor to connect to Relay	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$	1.50



TAPE DISPENSERS • LABEL DISPENSERS • NON-ADHESIVE CUTTERS

## LabelMoto DISPENSER Parts List

				1	(
Part #	Description	Image	Notes	Used On	Price
ELE-030-01	115V - 25 RPM AC Motor		25 RPM motor for short labels	LD6025 & LDX6025 Series, LD8025 & LDX8025 Series	\$ 116.20
ELE-030-02	220V - 25 RPM AC Motor - CE		25 RPM motor for short labels	LD6025 & LDX6025 Series, LD8025 & LDX8025 Series	\$ 116.20
ELE-030-03	115V - 50 RPM AC Motor	8	Standard motor for all LD models	LD6050 & LDX6050 Series, LD8050 & LDX8050 Series	\$ 111.20
ELE-030-04	220V - 50 RPM AC Motor - CE		Standard motor for all LD models	LD6050 & LDX6050 Series, LD8050 & LDX8050 Series	\$ 111.60
ELE-030-05	115V - 100 RPM AC Motor		Super Speed option for faster dispening time	LD6100 & LDX6100 Series, LD8100 & LDX8100 Series	\$ 120.80
ELE-030-06	220V - 100 RPM AC Motor - CE		Super Speed option for faster dispening time	LD6100 & LDX6100 Series, LD8100 & LDX8100 Series	\$ 123.30
ELE-031-01	DC Motor for LD3000 & LD3500		Needs Screw, OTS-016-01 to mount onto main plate	LD3000 & LD3500	\$ 31.70
ELE-032-01	Rear Power Switch for AC Label Dispensers		Suggested to purchase ASM-012-01 for easy and fast replacement.	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 3.00
ELE-032-02	Front Power Switch for AC Label Dispensers		Only used for machines with the switch on the FRONT of the machine.	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 5.80
ELE-033-01	AC Photo Sensor - Standard			LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 111.70
ELE-033-02	Photo Sensor - For Clear Materials		Used on "C" Models of LD's. Works with regular labels as well.	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 224.70
ELE-034-01	Solid State Relay For AC LD's		Before Disassembling wires, check connections for easy replacment on the 4 connector pins.	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 25.70
ELE-035-01	AC Power Inlet for LD's		Suggested to purchase ASM-012-01 for easy replacement.	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 4.60



TAPE DISPENSERS • LABEL DISPENSERS • NON-ADHESIVE CUTTERS

## LabelMoto DISPENSER Parts List

Part #	Description	Image	Notes	Used On	Pi	rice
ELE-043-01	12V DC Power Supply, 100-240V AC Input	5	Suggested to purchase Power Cord as well, ELE-044	LD3000, LD3500 & LR4500	\$	28.30
POWERADAPTOR-C	Euro Plug Adaptor (France, Italy, etc)		This is an Adaptor only used with Euro / Schuko plugs for countries that use a smaller diameter pin plug.	Schuko Plug	\$	3.70
ELE-044-01 POWERCORD-B	Power Cord - USA		3 Prong, Grounded, 6 Foot (2m) Powercord	All Label Dispensers	\$	6.90
ELE-044-04 POWERCORD-B25	Power Cord - USA 25' Long		3 Prong, Grounded, 25 Foot (11.8m) Powercord	All Label Dispensers	\$	26.60
ELE-044-02 POWERCORD-F	Power Cord - Euro (Schuko)		2 Prong, Grounded, 2 meter Powercord	All Label Dispensers	\$	10.70
ELE-044-03 POWERCORD-G	Power Cord - UK		3 Prong, Grounded, 2 meter Powercord	All Label Dispensers	\$	13.20
ELE-046-01	Fuse, 5amp, 250V, 5F	Till Control of the C	Assembled inside the AC Power Inlet (ELE-035-01).	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$	2.20
ELE-047-01	Insulated Spade Terminal		Used on wiring to connect motor wire to relay and Connects to Black wire on AC Photosensor	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$	1.60
ELE-048-01	3 Port Connector		Used when having to replace wiring.	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$	1.80
ELE-049-01	4 Port Connector		Used when having to replace wiring.	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$	1.80
ELE-050-01	3 Port Push-In Wire Connector for LR		Used when having to replace wiring.	LR4500	\$	2.20
OTS-002-01	FHCS , #10-32X1", Screws for Strip Plate, Guide Rod and 2 spaces on the main plate	0	1/8" Hex Wrench needed	LD6000 & LDX6000 Series	\$	1.50
OTS-003-01	BHCS, Button Head, 10-32 x 1" for LD6050 Main Plate		1/8" Hex Wrench needed	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$	1.50



TAPE DISPENSERS • LABEL DISPENSERS • NON-ADHESIVE CUTTERS

## LabelMoto DISPENSER Parts List

Part #	Description	Image	Notes	Used On	Pi	rice
OTS-003-02	BHCS, Button Head, 10-32 x .5" for Brush and Sensor Bracket (Perment Mounting)		Optional part to permantly secure the sensor bracket and Brush Holder	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$	1.50
OTS-003-03	BHCS, Button Head, 10-32 x .375" for LD6050 Relay & Secure mount for sensor		Used to mound relay on AC Wiring Plate (ASM-012-01)	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$	1.50
OTS-004-01	Screws for End Cap for Motor Cover (FHCS, #10-32X.5")			LD3000, LD3500, LD6000 & LDX6000 Series, LD8000 and LDx8000 Series	\$	1.50
OTS-005-01	Wing Screw for Brush Holder and Sensor Bracket (10-32 x .5")		Used for the Brush Holder and Sensor Bracket	LD3000, LD3500, LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$	1.90
OTS-007-01	Thumbscrews for Sensor Nut Plate (#4-40X.75")		Used to adjust the Sensor Horizontally on the Sensor Bracket	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$	2.50
OTS-007-02	Thumbscrews for Sensor Nut Plate (#4-40 X .5")		Used to adjust the Sensor Horizontally on the Sensor Bracket	LD3000 & LD3500	\$	2.50
OTS-007-03	Thumbscrews for CLEAR Sensor Nut Plate (#4-40 X 1")		Used to adjust the Sensor Horizontally on the Sensor Bracket	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$	2.70
OTS-010-01	Ground Wire & Sensor Bracket, Hex Nut (#10-32)		Nut, Used for the Ground wire and Permanent mounting of sensor bracket	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$	1.30
OTS-011-01	Screws for Reel Holder Arm (PRT-019-01) (FHCS, #5/16-18X3/4)		Mounts to the Motor Cover and the Reel Hanger Bar (3/16" Hex needed)	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$	1.80
OTS-011-02	Screw for Reel Holder Arm (PRT-019-01) (BHCS, #5/16-18X3/4)		Mounts to the Frame of the machine, Reel Hanger Bar (3/16" Hex needed)	LD8000, LDX8000, LDXL8000 Series	\$	2.00
OTS-012-01	Core Holder - 3" (76mm)		Converts 3" Label rolls to 1" to mount properly on the Reel Holder Bar	LD3000, LD3500, LD6000 & LDX6000 Series, LD8000 & LDX8000 Series		1.30
OTS-013-01	Core Holder - 6" (152mm)		Converts 6" ID Label rolls to 3" to mount properly on the Reel Holder Bar	LDHangTab	\$	6.70
OTS-015-01	Set Screw for Take-Up Hub (PRT-017) (8-32X.25/Black)		Used to mount the Take-Up Hub (PRT- 017.1) on the motor Shaft (2mm Hex wrench needed to tighten)	LD6000 & LDX6000	\$	1.80



TAPE DISPENSERS • LABEL DISPENSERS • NON-ADHESIVE CUTTERS

## LabelMoto DISPENSER Parts List

Part #	Description	Image	Notes	Used On	Price	e
OTS-015-02	Set Screw for Take-Up Hub (PRT-016) (8-32X.125/Black)		Used to mount the Take-Up Hub (PRT- 016.1) on the motor Shaft (2mm Hex wrench needed to tighten)	LD3000 & LD3500	\$ 2.	.00
OTS-015-03	Set Screw for Take-Up Hub (PRT-015) (10-32X.125/Black)		Used to mount the Take-Up Hub (PRT- 015) on the motor Shaft (3-32 Hex wrench needed to tighten)	LD8000 & LDX8000 Series	\$ 1.	.90
OTS-016-01	FHCS, M3 X 8	<b>Bunnam</b>	Used to mount motor onto the main plate (2mm Hex wrench needed to tighten)	LD3000 & LD3500	\$ 1.	.90
OTS-022-01	Hex Key, 3/16"		Used with OTS-011-01 Screw mounted on PRT-019-01	LD3000, LD3500, LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 1.	.90
OTS-024-01	Hex Stand-off for PCB		Used for mounting the PCB onto the PCB mounting plate	LD30000 & LD3500	\$ 1.	.90
OTS-026-01	BHCS #4-40 X .25"		Used for mounting the PCB onto the PCB mounting plate	LD30000 & LD3500	\$ 1.	.60
OTS-028-01	#10 Washer, Stainless Steel, (MIL Spec AN960-C10L)	0	Very thin Washer for smooth adjustment of PRT-018. Also used for permanent mounting of Sensor Bracket and Brush Holder	LD6025, LD6050, LD6100	\$ 1.	.30
OTS-040-01	Rubber Feet		Rubber Feet used on the bottom of all Machines	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 1.	.40
OTS-043-01	Screw, Thread Forming Type B, #10-16 X 1" (.125" Hex)		Only Used if for some reason your existing 1" 10-32 screw became stripped out.	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 1.	.50
OTS-050-01	Cable Tie Mount		Used in harnessing wire assembly inside the machine	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 1.	.40
OTS-051-01	Cable Ties		Used in harnessing wire assembly inside the machine	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 1.	.10
OTS-054-01	10-32 Stainless Shoulder Screw		Used as the axis point for the brush holder for the LD8000 and LX 8000 Series	LD8000, LDX8000, LDXL8000 Series	\$ 6.	.90
OTS-055-01	#10 Stainless Steel Star Washer (EXTERNAL Teeth)	*Q	Used for grounding point on the AC Label Dispensers	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 1.	.10



TAPE DISPENSERS • LABEL DISPENSERS • NON-ADHESIVE CUTTERS

LabelMoto DISPENSER Parts List

Part #	Description	Image	Notes	Used On	Price
OTS-055-02	#10 Stainless Steel Star Washer (INTERNAL Teeth)		Used for grounding point on the AC Label Dispensers	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 1.1
PRT-003-01	Strip Plate For LD6000	Cor or	Needs Screw OTS-002-01 to properly mount	LD6000 Series	\$ 26.7
PRT-003-02	Strip Plate For LDX6000	GOT OF	Needs Screw OTS-002-01 to properly mount	LDX6000 Series	\$ 28.5
PRT-003-03	Strip Plate For LD5000	Cor or	Needs Screw OTS-002-01 to properly mount	LD5000 Series	\$ 26.2
PRT-003-04	Strip Plate for LD3500 Series	Garage	Needs Screw OTS-002-01 to properly mount	LD3500	\$ 24.1
PRT-005-01	Material Guide for Guide Rod, Large (Standard) 1" ID		For use with PRT-016 and PRT-016.1	LD3000, LD3500, LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 8.3
PRT-076-01	Material Guide for Guide Rod (Metal), Large 1" ID		For use with and PRT-016.1 and PRT-016.2	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 22.1
PRT-011-01	Motor Cover for LD and LDX Series Dispenser		Needs Screw OTS-002-01 and OTS-003-01 to properly mount	LD6000 & LDX6000 Series	\$ 42.1
PRT-011-02	Motor Cover for LD3000 &LD3500		Needs Screw OTS-002-01 and OTS-003-01 to properly mount	LD3000 & LD3500	\$ 38.7
PRT-011-04	Motor Cover for LD8000 & LDX8000	D	Needs Screw OTS-002-01 and OTS-003-01 to properly mount	LD8000 & LDX8000 Series	\$ 49.6
PRT-013-01	End Cap for Motor Cover		Needs Screw OTS-004-01 to properly mount	LD3000 & LD3500 Series, LD6000 & LDX6000 Series	\$ 19.4
PRT-014-01	Main Plate for LD6000 and LDX6000	100		LD6000 & LDX6000 Series	\$ 70.9



TAPE DISPENSERS • LABEL DISPENSERS • NON-ADHESIVE CUTTERS

LabelMoto DISPENSER Parts List

Part #	Description	Image	Notes	Used On	Price
PRT-014-05	Main Plate for LD3000 & LD3500			LD3000 & LD3500	\$ 67.70
PRT-015-01	Take-Up Hub Roller - 1.5" For LD8000, 5.5" Length		Needs 2 Set Screws, OTS-015-03	LD8000 Series	\$ 20.10
PRT-015-02	Take-Up Hub Roller - 1.5" For LDX8000, 8.5" Length		Needs 2 Set Screws, OTS-015-03	LDX8000 Series	\$ 24.10
PRT-016.1-01	Take-Up Hub - 1" For LD3000, 2.75" Length		Needs Screw, OTS-015-02 to mount onto motor shaft	LD3000 & LD3500	\$ 14.30
PRT-016.1-03	Reel Hanger Bar - 1" For LD6000, 5.5" Length		Needs Screw, OTS-011-01 to mount onto PRT-019-01	LD6000 Series	\$ 15.50
PRT-016.1-06	Reel Hanger Bar - 1" For LDX6000, 7.75" Length		Needs Screw, OTS-011-01 to mount onto PRT-01	LDX6000 Series	\$ 15.90
PRT-016.1-07	Reel Hanger Bar - 1" For LDX8000, 8.25" Length		Needs Screw, OTS-011-02 to mount onto main plate	LDX8000 Series	\$ 15.50
PRT-016.1-09	Reel Hanger Bar - 1" For LD3000, 3.1" Length		Needs Screw, OTS-011-01 to mount onto PRT-019-03	LD3000, LD3500	\$ 12.30
PRT-016.1-11	Take Up Hub Roller for LD3000-J, 3" Length		Needs Screw, OTS-015-02 to mount onto motor shaft	LD3000-J	\$ 14.70
PRT-016.1-12	Reel Hanger Bar for LD3000-J, 3.35" Length		Needs Screw, OTS-011-01 to mount onto PRT-019-03	LD3000-J	\$ 12.70
PRT-017.1-02	Take-Up Hub Roller - 1.25" For LD6000, 5.5" Length		Needs Screw, OTS-015-01 to mount onto motor shaft	LD6000 Sereies	\$ 25.10
PRT-017.1-03	Take-Up Hub Roller - 1.25" For LDX6000, 8" Length		Needs Screw, OTS-015-01 to mount onto motor shaft	LDX6000 Series	\$ 27.00



TAPE DISPENSERS • LABEL DISPENSERS • NON-ADHESIVE CUTTERS

## LabelMoto DISPENSER Parts List

Part #	Description	Image	Notes	Used On	Price
PRT-018.1-02	Photo Sensor Mounting Bracket for LD6000, 5.5" Length			LD6000, LD8000, LDX8000, LDXL8000 Series	\$ 16.6
PRT-018.1-03	Photo Sensor Mounting Bracket for LDX6000			LDX6000 Series	\$ 25.2
PRT-018.1-04	Photo Sensor Bracket for LD2000, LD3000, 2.75" Length			LD2000 & LD3000	\$ 11.1
PRT-018.1-05	Photo Sensor Bracket for LD3000 & LD3500, 2.75" Length			LD3000 & LD3500	\$ 7.10
PRT-019-01	Reel Holder Arm for LD6000 and LDX6000, 8" Length		Two OTS-011-01 screws needed, This part is an optional accessory for the LD3000 and LD3500. It is a necessary part to hang the machine from the rear 1/4" hanging bracket.	LD3000, LD3500, LD6000 & LDX6000 Series	\$ 17.1
PRT-019-03	LD3000 & LD3500 Reel Hanger Arm		Two OTS-011-01 screws needed	LD3000 & LD3500	\$ 14.7
PRT-020-01	Lock Rod for LD3000 & LD3500	3		LD3000 & LD3500	\$ 6.9
PRT-020-02	Lock Rod for LD3000-J	N		LD3000-J	\$ 9.8
PRT-020.1-03	Lock Rod for LD6000 Series	1		LD6000 Series	\$ 10.1
PRT-020.1-06	Lock Rod for LDX6000 Series	1		LDX6000 Series	\$ 12.1
PRT-020.2-01	Lock Rod for LD8000 Series			LD8000 Series	\$ 13.0
PRT-020.2-02	Lock Rod for LDX8000 Series			LD8000 Series	\$ 14.4



TAPE DISPENSERS • LABEL DISPENSERS • NON-ADHESIVE CUTTERS

LabelMoto DISPENSER Parts List

Part #	Description	Image	Notes	Used On	Price
PRT-021-01	Strip Plate for LD3000		Needs Screw OTS-002-01 to properly mount	LD3000	\$ 13.00
PRT-021-03	Strip Plate for LD3000-J		Needs Screw OTS-002-01 to properly mount	LD3000-J	\$ 13.60
PRT-022-01	Guide Rod Bumped for LD3000, 2.75" Length	6	Needs Screw OTS-002-01 to properly mount	LD3000, LD3500	\$ 8.90
PRT-022-03	Guide Rod Bumped, 5.5" Length	6	Needs Screw OTS-002-01 to properly mount	LD6000 Series, LD8000 Series	\$ 11.50
PRT-022-04	Guide Rod Bumped for LDX6000, 8" Length		Needs Screw OTS-002-01 to properly mount	LDX6000 Series	\$ 12.30
PRT-022-07	Guide Rod Bumped for LDX8000, 8.25" Length		Needs Screw OTS-002-01 to properly mount	LDX8000 Series	\$ 12.70
PRT-022-09	Guide Rod Bumped for LD3000-J, 3.3" Length	6	Needs Screw OTS-002-01 to properly mount	LD3000-J	\$ 9.90
PRT-023-01	Material Guide for Guide Rod, Small	6	Part fits on PRT-022 Guide Rod	LD3000, LD3500, LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 3.50
PRT-024-01	LDX6000 Base Extension, 8.75"			LDX6000 Series	\$ 43.60
PRT-31-01	Brush Holder Tensioner for LD8000 Series			LD8000, LDX8000, LDXL8000 Series	\$ 31.10
PRT-032-01	Guide Rod Spacer, .25" x .6"		Used on Versions of the LD6000 Series from 2013, not necessary for machine to function properly	LD6000 Series	\$ 4.20
PRT-037-01	Main Plate for the LD8000			LD8000 Series	\$ 109.10

TAPE DISPENSERS • LABEL DISPENSERS • NON-ADHESIVE CUTTERS

LabelMoto DISPENSER Parts List

Part #	Description	Image	Notes	Used On	Price
PRT-037-02	Main Plate for the LDX8000			LDX8000 Series	\$ 117.10
PRT-038-01	End Cap for Motor Cover for LD8000's			LD8000, LDX8000, LDXL8000 Series	\$ 32.10
PRT-040-01	Back Support for the LD8000 Series	7	Needs Screw, OTS-004-01 to mount onto main plate	LD8000 Series	\$ 41.10
PRT-040-02	Back Support for the LDX8000 Series	7	Needs Screw, OTS-004-01 to mount onto main plate	LDX8000 Series	\$ 57.10
PRT-041-01	Strip Plate for the LD8000 Series (5.5" Wide)			LD8000 Series	\$ 65.10
PRT-041-02	Strip Plate for the LDX8000 Series (8.5" Wide)			LDX8000 Series	\$ 79.10
PRT-042-01	Photosensor Mount for the LD3000 and LD3500		Needs Screw, OTS-007-02 to mount onto the sensor bracket	LD3000 & LD3500	\$ 16.10
PRT-058-01	PCB Mounting Plate(Plate Only)		QTY 4 of OTS-024-01 and OTS-026-01 are needed to mount the PCB	LD3000 & LD3500	\$ 16.90
PRT-059-01	Nut Plate for Standard Photo Sensor	•	Needs Screw, OTS-007-01 to mount onto the sensor bracket	LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 6.90
PRT-059-02	Nut Plate for Clear Photo Sensor			LD6000 & LDX6000 Series, LD8000 & LDX8000 Series	\$ 14.10
PRT-091-01	Lock Rod Space Filler for LD6000 & LDX6000		This is used to fill in the open space in the lock rod. Only used for those clients that have special requirements.	LD6000 & LDX6000 Series	\$ 14.90